

How to use the Laser Pointer USB remote control

Laser Pointer USB Basic Instructions

Components

- Laser pointer
- USB receiver
- Extra batteries

How to use it!

1. Plug the USB receiver into your computer
2. Open a Power Point presentation
3. The laser beam button, the page down button, and the page up button are all located along the side of the pointer with the laser beam emitting from the end with the buttons
4. The page down and up buttons can be used to move between slides in your presentation

Revision #2

Created 19 February 2019 22:32:07

Updated 8 October 2019 17:02:35